



Classic Garden Elements®

Tips for installing THE MALMAISON ROSE PYRAMID PARK

Firstly, you need to connect all four spikes to the Pyramid and secure them with small screws (provided). A process best carried out when the structure is lying on the ground.

Then you need to dig four holes for the spikes. Each hole needs to be around 80cm deep. In cold, frost prone regions make it 110cm deep. Then fill the hole with drainage material – something like fine gravel, for example. Compress the gravel using an earth rammer – so that in the end the hole will be around 50cm deep: Each spike is 50cm long. Now position the Pyramid with all four spikes into the four pre-prepared holes. Use a laser spirit level to ensure that everything is vertical.

Next you need to fix the Pyramid in place so that it cannot move, using wooden supports. When it's secure and in the perfect position only then fill up the four holes with more fine gravel. Compress the fine gravel using an earth rammer. Make sure while doing this that the Pyramid remains vertical at all times - using a laser spirit level during work for control. There is no need to fill the four holes with concrete.

Finally remove all supports and start planting.

And that's it!

