



Classic Garden Elements®

This is special work for hard landscape gardeners

Tall Garden Obelisks that need to be cemented into the ground

A Classic Garden Elements Tall Garden Obelisk is an incredibly sturdy and stormproof structure, assuming you install it correctly.

Tips for installing a Tall Garden Obelisk

Firstly, you need to connect the spike to the Obelisk and secure it with a small screw (provided). A process best carried out when the structure is lying on the ground.

Then you need to dig the hole for the foundation. The hole needs to be around 80cm deep. In cold, frost prone regions make it 110cm deep. Then fill the hole with drainage material – something like fine gravel, for example. Then compress the gravel using an earth rammer – so that in the end the hole will be around 60cm deep: The spike is 60cm long. Now position the Tall Garden Obelisk with Spike into the pre-prepared hole. Use a laser spirit level to ensure that everything is vertical.

Next you need to fix the Tall Garden Obelisk with Spike in place so that it cannot move, using large stones and wooden supports. When it's secure and in the perfect position only then pour quick-setting concrete into the hole. Leave the concrete to cure, which usually takes around three days. Make sure you leave the supports in place as the concrete hardens.

Finally remove all supports and start planting.

And that's it!







